



## AIR SEALING

# Spray Foam

Spray foam can reduce the amount of air that leaks in and out of your home. Cut heating and cooling costs, increase comfort, and create a healthier indoor environment by using spray foam at gaps in your home's walls.

Follow these four easy steps



step one

### Prepare the can


Follow the directions on the back of the spray foam can to prepare correctly.



step two

### Perform a test

The spray foam expands quickly, so test the spray foam on a different area to make sure you are comfortable using and applying the product.



step three

### Fill the hole

Point the nozzle tip into the hole and begin to spray. Fill until hole is no longer a source of leaking air. Be sure to use spray foam only in well-ventilated areas.



step four

### Trim the excess

Allow foam to dry before trimming excess or spraying another layer of foam.



**Spray Foam Tips:** The foam dries quickly, so it is recommended to use all of the can's contents within a few hours; also use safety glasses and avoid getting the foam on exposed skin or clothes.